





NOTES:

1. ALL RESISTORS ARE 1/2 WATT 5% UNLESS OTHERWISE NOTED. RESISTOR VALUES ARE IN OHMS (K=1000).
2. ALL CAPACITORS LESS THAN 1 ARE IN μF, GREATER THAN 1 ARE IN pF.
3. FUNCTION SWITCH SHOWN IN 200 POSITION.
4. CALIBRATE SWITCH SHOWN IN CAL POSITION.
5. SENSITIVITY SWITCH SHOWN PUSHED IN.
6.  THIS SYMBOL INDICATES CIRCUIT BOARD COMMON.
7.  THIS SYMBOL INDICATES CHASSIS GROUND.
8.  THIS SYMBOL INDICATES AN EXTERNAL CONNECTION TO THE CIRCUIT BOARD.
9.  THIS SYMBOL INDICATES A FERRITE BEAD.

SCHEMATIC OF THE
HEATHKIT[®]
RF POWER METER
MODEL HM-102

PRINTED CIRCUIT BOARD

